

HURACAN-X

DMX channel's functions and their values (70DMX channels):

Mode/Channel			Value	Function
St	Ba	Ex		
1	1	1		PAN Movement 8bit :
			0-255	Pan Movement
2		2		Pan Fine 16bit
			0-255	Fine control of Pan movement
3	2	3		TILT Movement 8bit :
			0-255	Tilt Movement
4		4		Tilt Fine 16bit
			0-255	Fine control of Tilt movement
5	3	5		Speed Pan/Tilt movement:
			0-225	max to min speed
			226-235	blackout by movement
			236-245	blackout by all wheel changing
6	4	6		Shutter, strobe:
			0-10	Shutter closed
			11-20	No function (shutter open)
			21-117	Strobe effect slow to fast
			118-126	No function (shutter open)
			127-180	Pulse-effect in sequences
			181-191	No function (shutter open)
			192-245	Random strobe effect slow to fast
246-255	No function (shutter open)			
7	5	7		Dimmer intensity:
			0-255	Intensity 0 to 100%
		8		Fine Dimmer intensity:
		8	0-255	Dimmer intensity fine
8	6	9		Zoom :
			0-255	Zoom adjustment from small to big
		10		Zoom Fine:
		10	0-255	Zoom adjustment Fine
9	7	11		Focus :
			0-255	Continuous adjustment from near to far
		12		Focus Fine:
		12	0-255	Continuous adjustment Fine
10	8	13		Auto Focus :
			0-50	Auto Focus Off
			51-100	5m
			101-150	7.5m
			151-200	10m
		14		AutoFocus Fine:
11	9	14	0-255	Continuous adjustment Fine

12	10	15		Color Wheel:
			0-3	Open / white
			4-7	Color 1
			8-11	Color 2
			12-15	Color 3
			16-19	Color 4
			20-23	Color 5
			24-27	Color 6
			28-127	Color indexing
			128-189	Backwards rainbow effect from fast to slow
			190-193	No rotation
194-255	Forwards rainbow effect from slow to fast			
		16		Color Wheel Fine:
			0-255	Color Wheel colour change to any position Fine
13	11	17		Cyan Color :
			0-255	Cyan (0-white, 255-100% Cyan)
		18		Cyan Color Fine :
			0-255	Cyan Fine
14	12	19		Magenta Color :
			0-255	Magenta (0-white, 255-100% magenta)
		20		Magenta Color Fine :
			0-255	Magenta Fine
15	13	21		Yellow Color :
			0-255	Yellow (0-white, 255-100% Yellow)
		22		Yellow Color Fine :
			0-255	Yellow Fine
16	14	23		CTO Color :
			0-255	CTO (0-white, 255-100% CTO)
		24		CTO Color Fine :
			0-255	CTO Fine
17	15	25		CTB Color :
			0-255	CTB (0-white, 255-100% CTO)
		26		CTB Color Fine :
			0-255	CTB Fine
18	16	27		CTP Color :
			0-255	CTP (0-white, 255-100% CTO)
		28		CTP Color Fine :
			0-255	CTP Fine
19	17	29		Color Presets:
			0-255	See Appendix
20	18	30		Chase Patterns:
			0-9	Open
			10-19	Chase 1
			20-29	Chase 2
			30-39	Chase 3
			40-49	Chase 4
			50-59	Chase 5
			60-69	Chase 6
			70-79	Chase 7
			80-89	Chase 8
			90-99	Chase 9
			100-109	Chase 10
			110-119	Chase 11
			120-129	Chase 12
			130-139	Chase 13
140-255	Reserved			
21	19	31	0-125	Chase Speed: Fast to Slow Backward
			126-130	Stop(Speed=0)
			131-255	Slow to Fast Forward
22	20	32		Chase Fade:
			0-255	Fade Chase

23	21	33		Rotating gobos, cont. rotation 1:
			0-9	Open
			10-19	Rot. gobo 1
			20-29	Rot. gobo 2
			30-39	Rot. gobo 3
			40-49	Rot. gobo 4
			50-59	Rot. gobo 5
			60-69	Rot. gobo 6
			70-77	Rot. Gobo 7
			78-93	Gobo 1 shake slow to fast
			94-109	Gobo 2 shake slow to fast
			110-125	Gobo 3 shake slow to fast
			126-141	Gobo 4 shake slow to fast
			142-157	Gobo 5 shake slow to fast
			158-173	Gobo 6 shake slow to fast
			174-189	Gobo 7 shake slow to fast
190-221	Gobo wheel rotation backwards from fast to slow			
222-223	No rotation			
224-255	Gobo wheel rotation forwards from slow to fast			
24	22	34		Rotating gobo index,rotating gobo rotation 1:
			0-127	Gobo indexing
			128-189	Forwards gobo rotation from fast to slow
			190-193	No rotation
			194-255	Backwards gobo rotation from slow to fast
		35		Rotating gobo indexing Fine 1:
			0-255	Fine indexing
25	23	36		Rotating gobos, cont. rotation 2:
			0-9	Open
			10-19	Rot. gobo 1
			20-29	Rot. gobo 2
			30-39	Rot. gobo 3
			40-49	Rot. gobo 4
			50-59	Rot. gobo 5
			60-69	Rot. gobo 6
			70-77	Rot. Gobo 7
			78-93	Gobo 1 shake slow to fast
			94-109	Gobo 2 shake slow to fast
			110-125	Gobo 3 shake slow to fast
			126-141	Gobo 4 shake slow to fast
			142-157	Gobo 5 shake slow to fast
			158-173	Gobo 6 shake slow to fast
			174-189	Gobo 7 shake slow to fast
190-221	Gobo wheel rotation backwards from fast to slow			
222-223	No rotation			
224-255	Gobo wheel rotation forwards from slow to fast			
26	24	37		Rotating gobo index,rotating gobo rotation 2:
			0-127	Gobo indexing
			128-189	Forwards gobo rotation from fast to slow
			190-193	No rotation
			194-255	Backwards gobo rotation from slow to fast
		38		Rotating gobo indexing Fine 2:
			0-255	Fine indexing
27	25	39		Animation wheel 1:
			0-7	No rotation
			8-127	Forwards rotation from fast to slow
			128-135	No rotation
			136-255	Backwards rotation from slow to fast
28	26	40		Animation wheel 2:
			0-255	Animation indexing
29	27	41		Rotating Animation wheel 2:
			0-7	No rotation
			8-127	Forwards rotation from fast to slow
			128-135	No rotation
			136-255	Backwards rotation from slow to fast

30	28	42		Iris:
			0-191	Max. diameter to Min.diameter
			192-223	Pulse closing fast to slow
			224-255	Pulse opening slow to fast
		43		Iris Fine:
			0-255	Iris Fine
31	29	44		Prism 1:
			0-127	Open
			128-255	5-Facet Prism
32	30	45		Rotating prism index, rotating prism rotation 1
			0-127	Prism indexing
			128-189	Forwards prism rotation from fast to slow
			190-193	No rotation
			194-255	Backwards prism rotation from slow to fast
		46		Rotating prism indexing Fine 1:
			0-255	Fine indexing
33	31	47		Prism 2:
			0-127	Open
			128-255	Linear Prism
34	32	48		Rotating prism index, rotating prism rotation 2
			0-127	Prism indexing
			128-189	Forwards prism rotation from fast to slow
			190-193	No rotation
			194-255	Backwards prism rotation from slow to fast
		49		Rotating prism indexing Fine 2:
			0-255	Fine indexing
35	33	50		Frost 1:
			0-255	0-100%
36	34	51		Frost 2:
			0-255	0-100%
37	35	52		Blade 1A :
			0-255	Open to Close
		53		Blade 1A Fine :
			0-255	Open to Close Fine
38	36	54		Blade 1B :
			0-255	Open to Close
		55		Blade 1B Fine :
			0-255	Open to Close Fine
39	37	56		Blade 2A :
			0-255	Open to Close
		57		Blade 2A Fine :
			0-255	Open to Close Fine
40	38	58		Blade 2B :
			0-255	Open to Close
		59		Blade 2B Fine :
			0-255	Open to Close Fine
41	39	60		Blade 3A :
			0-255	Open to Close
		61		Blade 3A Fine :
			0-255	Open to Close Fine
42	40	62		Blade 3B :
			0-255	Open to Close
		63		Blade 3B Fine :
			0-255	Open to Close Fine
43	41	64		Blade 4A :
			0-255	Open to Close
		65		Blade 4A Fine :
			0-255	Open to Close Fine
44	42	66		Blade 4B :
			0-255	Open to Close
		67		Blade 4B Fine :
			0-255	Open to Close Fine
45	43	68		All Blade Rotation :
			0-255	All Blade Rotation
		69		All Blade Rotation Fine :
			0-255	All Blade Rotation Fine

46	44	70		Control, reset, internal programs:
			0-4	unused
			5-9	Display Off
			10-14	Display On
			15-19	Display Invert Off
			20-24	Display Invert On
			25-29	Auto fan control mode
			30-34	Stage fan control mode
			35-39	Studio fan control mode
			40-41	Silence fan control mode
			42-44	Theatre fan control mode
			45-49	Square Law
			50-54	Linear
			55-57	1.2K
			58-60	2.4K
			61-63	16K
			64-69	25K
			70-74	Gobo correction Off
			75-79	Gobo correction On
			80-84	All motor reset
			85-87	Scan motor reset
			88-90	Colors motor reset
			91-93	Gobo motor reset
			94	unused
			95	Reset P/T Fade Off
			96	Reset P/T Fade On
			97-99	Other motor reset
100-255	unused			

Appendix

name (=DMX value)	color name
EC003	LAVENDER TINT
EC004	MEDIUM BASTARD AMBER
EC007	PALE YELLOW
EC008	DARK SALMON
EC009	PALE AMBER GOLD
EC010	MEDIUM YELLOW
EC013	STRAW TINT
EC015	DEEP STRAW
EC017	SURPRISE PEACH
EC020	MEDIUM AMBER
EC021	GOLD AMBER
EC022	DARK AMBER
EC024	SCARLET
EC025	SUNSET RED
EC026	BRIGHT RED
EC029	PALSA RED
EC035	LIGHT PINK
EC036	MEDIUM PINK
EC046	DARK MAGENTA
EC048	DARK PURPLE
EC052	LIGHT LAVENDER
EC053	PALE LAVENDER
EC058	LAVENDER
EC063	PALE BLUE
EC068	SKY BLUE
EC071	TOKIO BLUE
EC075	EVENING BLUE
EC079	JUST BLUE
EC085	DEEPER BLUE
EC088	LIME GREEN
EC089	MOSS GREEN
EC090	DARKYELLOW GREEN
EC100	SPRING YELLOW
EC101	YELLOW
EC102	LIGHT AMBER
EC103	STRAW
EC104	DEEP AMBER
EC105	ORANGE
EC106	PRIMAY RED
EC107	LIGHT ROSE
EC108	ENGLISH ROSE
EC109	LIGHT SALMON
EC110	MIDDLE ROSE
EC111	DARK PINK
EC113	MAGENTA
EC116	MEDIUM BLUE GREEN
EC118	LIGHT BLUE
EC119	DARK BLUE
EC120	DEEP BLUE
EC124	DARK GREEN
EC126	MAUVE
EC127	SMOKEY PINK
EC128	BRIGHT PINK

EC132	MEDIUM BLUE
EC134	GOLDEN AMBER
EC136	PALE LAVENDER
EC137	SPECIAL LAVENDER
EC138	PALE GREEN
EC139	PRIMARY GREEN
EC140	SUMMER BLUE
EC141	BRIGHT BLUE
EC142	PALE VIOLET
EC143	PALE NAVY BLUE
EC147	APRICOT
EC148	BRIGHT ROSE
EC151	GOLD TINT
EC152	PALE GOLD
EC153	PALE SALMON
EC154	PALE ROSE
EC156	CHOCOLATE
EC158	DEEP ORANGE
EC159	NO COLOR STRAW
EC161	SLATE BLUE
EC162	BASTARD AMBER
EC164	FLAME RED
EC165	DAYLIGHT BLUE
EC169	LILAC TINT
EC170	DEEP LAVENDER
EC172	LAGOON BLUE
EC174	DARK STEEL BLUE
EC176	LOVING AMBER
EC179	CHROME ORANGE
EC180	DARK LAVENDER
EC181	CONGO BLUE
EC182	LIGHT RED
EC183	MOONLIGHT BLUE
EC192	FLESH PINK
EC193	ROSY AMBER
EC194	SURPRISE PINK
EC195	ZENITH BLUE
EC196	TRUE BLUE
EC197	ALICE BLUE
EC198	PALACE BLUE